## **Artsoft Helpdesk**

Portal > Wissendatenbank > FAQ's > Why does the machine not move the correct distance?

Why does the machine not move the correct distance? Imported User 6 - 2019-04-29 - in FAQ's

## The most likely causes are:

- The Steps Per Unit value for the axis is incorrect. (see related article)
- The motor for the axis is improperly tuned (acceleration and/or velocity are too high) which causes motor stalling and lost steps.
- There is an electrical problem between the controller and the drive.
- There is a mechanical issue such as backlash or slippage.