

Artsoft Helpdesk

Portal > Knowledgebase > Mach3 > Why is Mach3 telling me my machine has a "Abnormal Condition?"

Why is Mach3 telling me my machine has a "Abnormal Condition?"

Imported User 6 - 2019-04-29 - in Mach3

This button is calling attention to the fact that something has changed from what has been set as its "normal" state. Clicking on it will list the conditions that are not "normal", which can be something as simple as not having the machine homed. To set a new normal state, go to Operator and choose Set Normal Condition.